



燈號/Color	狀態/Status	對策/How to deal with
	未開機 Power off	使用USB線材，將RX連接到電源插座；若無反應請重新插拔插緊。 Please connect the receiver to the power socket with a USB cable. If it is already connected, try removing and inserting it.
	開機中 During startup	請等待直到開機完成 Please wait as it is.
	開機完成,待機中 Waiting	RX已開機完成，目前尚無TX投影。點擊TX上的按鈕開始投影 The receiver is running but not connected to the transmitter. If you want to start projection, please press the button on the transmitter.
	與TX配對中 During pairing	RX正與TX配對中。 Please wait as it is.
	與TX配對完成 Connection completed	與TX配對完成。點擊TX上的按鈕檢查畫面是否可投影。 Connection (pairing) with the transmitter has been completed. Please check that the computer screen can be projected on the projector.
	VIP模式 VIP mode	RX現在處於VIP模式，只有同為VIP藍燈模式的TX可以投影。 Prevents other transmitters from connecting during projection.
	供電不足 Insufficient power supply	若燈號有時為橘燈又轉為紅燈則為電源不足的情況，而不是故障。這時請重新插拔、將USB線材連接到電源插座，並確認是否插緊。 please check the USB cable connection. * If the color changes to orange in about one minute, this is not a malfunction. The power supplied from USB is insufficient. please connect to USB3.0 port or USB boat which can supply 1.0A.

燈號/Color	狀態/Status	對策/How to deal with
	未開機 Power off	使用USB線材，將TX連接到電源插座、或筆記型電腦有供電的USB埠；若無反應請重新插拔插緊。 Please connect the Transmitter to the power socket or USB port on laptop. If it is already connected, try removing and inserting it.
	開機中 During startup	請等待直到開機完成 Please wait as it is.
	開機完成,待機中 Waiting	TX已開機完成，點擊按鈕開始投影。 The Transmitter is running, press the button start to present.
	No video signal	TX沒有接收到訊號，請試著： HDMI規格：重新插拔HDMI線材，確實地將HDMI連接TX與筆記型電腦。 Type-C規格：重新插拔Type-C線材，確實地將type-C線材連接TX與筆記型電腦；若仍無訊號，請檢察您的筆記型電腦是否支援Display port or Thunderbolt 3 . No video signal is input. Button1: please connect the HDMI cable to the PC. If it is already connected, try removing and inserting it. Button 2: Try plugging / unplugging the cable. Please check the PC Type C interface support Display port or Thunderbolt 3 Function .
	VIP模式 VIP mode	RX現在處於VIP模式，只有同為VIP藍燈模式的TX可以投影。 Prevents other transmitters from connecting during projection.
	連接異常 Connection error	這通常是因為TX距離RX太遠，請將TX更靠近RX，在足夠的距離下燈號會轉為橘燈。 The paired receiver cannot be found. Place it near the receiver to be connected and wait for about 10 seconds. If the distance from the receiver is short enough, perform pairing with the receiver.